




## Multi Di@g Office usage notes


During installation, when Multi-Di@g configuration window appears, you should set *Communication interface* to USB and set *VCI serial number* to **A070026**:



After installation, MultiDiag shows message asking to get activation code:



Press green button and you will see window asking for code. Please contact us with the code (18-...) we will send you back the correct password to enter:



During the diagnostic with the device connected, warning about 0 days left will appear. Just check the mark “Do not display this message again” and continue the work, everything will be working ok.

